


















image.jpg









WARNING
Excessive tire pressure or overloading can cause loss of control and result in severe injury or death.
OPERATING TIRE PRESSURE
Tire pressure should be checked before each use.
Recommended
Front 20.0 psi (1.4 bar)
Rear 24.0 psi (1.7 bar)
Minimum
Front 18.0 psi (1.3 bar)
Rear 22.0 psi (1.6 bar)
Never add tire pressure to a tire with a flat. A flat tire can cause loss of control and result in severe injury or death.
LOADING
Maximum weight capacity: 100 kg (220 lbs.)
Maximum weight of operator, cargo and accessories: 100 kg (220 lbs.)
























image.jpg
























image.jpg



image.jpg



image.jpg



image.jpg







image.jpg



image.jpg

